



ILCS 2.0 UPGRADE KIT INSTRUCTION SHEET

INTRODUCTION

The ILCS 2.0 Upgrade Kit consists of an ILCS controller chip, external memory module (circuit board) with mounting bracket, data cable, and manuals. The enhanced version 2.0 ILCS WinReporter PC software (sold separately) is required to print reports from version 2.0 ILCS systems. The advantages of upgrading the ILCS system include:

- Expands the batch tracking memory from 750 time stamps to 6000 time stamps.
- Increases the number of users from 50 to 400.
- Increases the number of chemical formulas from 50 to 99.
- Version 2.0 ILCS WinReporter PC software (sold separately) uses a KCI module to communicate with the ILCS system, greatly improving communication speed for printing reports, or programming the setup. This new version is backward compatible with older ILCS systems.

INSTALLATION

Before upgrading the ILCS system, print any setup or usage reports that you may need. Be aware that setup (HEX) files for older systems are not compatible with the new 2.0 ILCS system, and the new system will not communicate with an RM-6000I. You will need to program new setup information once the installation is complete.

- (1) Turn all power to system off.
- (2) Remove the four screws from the front of the control box and carefully open the cover.
- (3) Locate the main EPROM chip on the control circuit board (identified as U15). Remove the chip by gently prying up with a small blade screwdriver.
- (4) Install the new chip provided in the kit. Be sure to line up the notch on the chip with the notch on the socket. Carefully press the chip into the socket ensuring that none of the pins on the chip are bent, or mis-aligned.
- (5) Install the external memory module in the back upper-right corner of the control box using the provided Dual-Lock adhesive strips. Ensure that the communication jack on the module is pointing downward.
- (6) Connect the external memory module to the ILCS control board with the short data cable provided. The right angle plug should go into the control board and the straight plug should go into the module.
- (7) Carefully close the cover of the control box, ensuring not to pinch any wires, and replace the four screws.
- (8) Turn the system power back on.

SETUP

Once you have installed the ILCS controller chip and the external memory module, you will need to setup the ILCS system to communicate with the memory module. After performing the steps below, you can then program the setup.

- (1) At the ILCS control panel, enter your access code for programming.
- (2) Go to menu #1 and press ENTER.
- (3) Answer "yes" to all of the menu prompts. This will clear the system memory and will set the ID of the memory module to match the system's ID number.
- (4) Process complete — press RESET until you get back to the default display.

NOTE: If the ID number of the ILCS system is changed at a later time, then the external memory module ID must also be changed. The included system programming manual will guide you through this process

DISCLAIMER

Knight Inc. does not accept responsibility for the mishandling, misuse, or non-performance of the described items when used for purposes other than those specified in the instructions. For hazardous materials information consult label, MSDS, or Knight Inc. Knight products are not for use in potentially explosive environments. Any use of our equipment in such an environment is at the risk of the user, Knight does not accept any liability in such circumstances.

WARRANTY

All Knight controls and pump systems are warranted against defects in material and workmanship for a period of ONE year. All electronic control boards have a TWO year warranty. Warranty applies only to the replacement or repair of such parts when returned to factory with a Knight Return Authorization (KRA) number, freight prepaid, and found to be defective upon factory authorized inspection. Bearings and pump seals or rubber and synthetic rubber parts such as "O" rings, diaphragms, squeeze tubing, and gaskets are considered expendable and are not covered under warranty. Warranty does not cover liability resulting from performance of this equipment nor the labor to replace this equipment. Product abuse or misuse voids warranty.

KNIGHT INC. A Unit of IDEX Corporation

World Headquarters: 20531 Crescent Bay Drive, Lake Forest, CA 92630-8825 (USA) TEL: 949-595-4800, FAX: 949-595-4801, www.knightequip.com

Atlanta Branch: 415 Gees Mill Business Court NE, Suite 200 Conyers, GA 30013 USA TEL: 770-760-8777 FAX: 770-761-0199	Toronto Branch: 2880 Argentia Road, Unit 6 Mississauga, Ontario L5N 7X8 Canada TEL: 905-542-2333 FAX: 905-542-1536	London Branch: #15 Brunel Centre Newton Road, Crawley West Sussex UK RH10 9TU TEL: 44-1293-615570 FAX: 44-1293-615585	Sydney Branch: Unit 28, 317-321 Woodpark Rd., Smithfield NSW Australia 2164 TEL: 61-29-725-2588 FAX: 61-29-725-2025	Amsterdam Branch: Marssteden 68 7547 TD Enschede The Netherlands TEL: 31-53-428-58-00 FAX: 31-53-428-58-09	Spain Branch: Port Ginesta, Local 210 08860 Sitges Barcelona Spain TEL: 34-936-342-130 FAX: 34-936-643-477
---	---	--	--	---	---