

KMP-AD (7865451) / KMP-AR (7865452) OPERATION GUIDE




Front View

- LED indicator
- Potentiometer
- 3 way power switch
OFF/ON/MOM
- Single pump with 2 lead
signal input cable
24 -240 VAC input



Bottom View

OPERATION



1. Connect signal input 24 to 240VAC
2. Prime pump by pressing and holding switch to MOM position until pump is primed
3. Turn main switch to ON
4. Pump will run and LED flash GREEN
5. Turn the potentiometer clockwise to increase speed of the pump
6. For pump to operate, leave switch to ON position
7. When signal activates pump will run at the set speed for however long the signal is present and the LED will flash intermittently GREEN

Note: If signal is on and the main switch in the OFF position the LED will FLASH intermittently RED